21/11/2018

MAXIMUM LIKELIHOOD FIT

PARAMETER ESTIMATION

You have a set of measurements $\{x_i\}$ of the same variable and a distribution hypothesis $f(x; \theta)$. You want to find the value of theta that best represents the measured data.

For this you can use a Maximum Likelihood estimator (ML), defined as

$$\boldsymbol{\theta}_{\mathrm{ML}} = \operatorname{argmax}_{\boldsymbol{\theta}} \mathbb{P} \left(\mathbf{x}, \boldsymbol{\theta} \right)$$

This estimator is proven to be unbiased and often the best you can use (it reaches the Cramer-Rao limit). We want just to prove that, by comparing the ML estimate to a real analytical solution. Let's use the exponential distribution for that.

$$f(x;\tau) = \frac{1}{\tau}e^{-x/\tau} \implies \mathcal{L}(\tau;\mathbf{x}) = \prod_{i=0}^{N-1} f(x_i;\tau) = \prod_{i=0}^{N-1} \frac{1}{\tau}e^{-x_i/\tau} \implies \ln \mathcal{L}(\tau;\mathbf{x}) = -N \ln \tau - \frac{1}{\tau} \sum_{i=0}^{N-1} x_i$$

The estimator we want is

$$\frac{d \ln \mathcal{L}}{d\tau} = 0 \Rightarrow \tau_{\text{ML}} = \frac{1}{N} \sum_{i=0}^{N-1} x_i$$

and its variance is

$$\mathbb{V}\left[\tau_{\mathrm{ML}}\right] = \mathbb{E}\left[-\frac{d^{2}\ln\mathcal{L}}{d\tau^{2}}\right]^{-1} = \frac{\tau_{\mathrm{ML}}^{2}}{N}$$

EX01: MUON LIFETIME

Suppose you measured for one hour incoming muons that stopped in your detector and decayed. You get ~500 muons and for each of them you recorded the time passed between the trigger and the detection of the decay products.


$$N \sim \text{Pois}(500); \quad f(x,\tau) = \frac{1}{\tau}e^{-x/\tau} \quad \Rightarrow \quad \tau_{\text{ML}} = ? \quad \mathbb{V}[\tau_{\text{ML}}] = ?$$

Estimate the muon lifetime and quote an error on the measurement using three different techniques:

- 1. Analytical solution of the ML problem
- 2. Scan (and plot) the $\ln 2$ profile and search for its maximum
- 3. Use a numerical minimisation tool (MINUIT / Minuit2) to find the minimum of $-\ln 2$
- 4. Build a histogram and use ROOT fit interface (TH1::Fit) to get an estimate of tau (try both the chi-square fit and the binned maximum-likelihood fit; what's the difference?)

Validate the variance you obtain using a toy MC

Bonus question: we don't need to know how much time passed between the muon creation in the atmosphere and it entering the detector. Why?



EX01: MUON LIFETIME

Suppose you measured for one hour incoming muons that stopped in your detector and decayed. You get ~500 muons and for each of them you recorded the time passed between the trigger and the detection of the decay products.


$$N \sim \text{Pois}(500); \quad f(x,\tau) = \frac{1}{\tau} e^{-x/\tau} \quad \Rightarrow \quad \tau_{\text{ML}} = ? \quad \mathbb{V}[\tau_{\text{ML}}] = ?$$

How to access the data: (you can get it from https://github.com/valerioformato/MLEstimate)

```
auto infile = TFile::Open("data/data.root");
auto tree = (TTree *)infile->Get("Triggers");


float t;
tree->SetBranchAddress("time", &t);

Long64_t nEv = tree->GetEntries();
for (Long64_t iEv = 0; iEv < nEv; iEv++) {
   tree->GetEntry(iEv);
   ...
}
```



EX01: (A) ANALYTICAL SOLUTION

$$\frac{d \ln \mathcal{L}}{d\tau} = 0 \Rightarrow \tau_{\text{ML}} = \frac{1}{N} \sum_{i=0}^{N-1} x_i$$



$$\mathbb{V}\left[\tau_{\mathrm{ML}}\right] = \mathbb{E}\left[-\frac{d^{2}\ln\mathcal{L}}{d\tau^{2}}\right]^{-1} = \frac{\tau_{\mathrm{ML}}^{2}}{N}$$


Looks like the easiest and most efficient solution (in terms of computational speed).

And it is.

But almost never you'll be so lucky to have a problem that can be solved analytically.

Real life fits are more complicated:

- Sum of p.d.f. from different contributions
- Large number of parameters
- p.d.f. not always analytical (MC templates)





EX01: (B) LIKELIHOOD SCAN

Select a range of values for au that you think includes the desired value. Scan the range computing $\ln 2$ for each value of au and

look for the maximum.

look for the maximum. The 68% confidence level interval can be found as
$$\left\{ au \in \mathbb{R} : \ln \mathcal{L}(au) > \ln \mathcal{L}(au_{\mathrm{ML}}) - rac{1}{2}
ight\}$$






EX01: (C) MINUIT

- Define your -ln∠ to minimize
- Pass it to MINUIT/Minuit2
- Minimize it

You can use the TMinuit interface or the ROOT::Math::Minimizer interface.



(Beware of TMinuit, it's deprecated and quite old)

(Beware of ROOT::Math::Minimizer, it's flexible and powerful, but requires some additional effort to make it work)

```
****
      1 **SET PRINT
      2 **SET NOGRAD
PARAMETER DEFINITIONS:
                     VALUE
                                             LIMITS
       NAME
                               STEP SIZE
                                             no limits
                  1.00000e-06 1.00000e-09
   1 tau
                          0.5
      3 **SET ERR
      4 **SET PRINT
****
      5 **SET STR
****
                                 0.001
      6 **MIGRAD
                      1e+06
****
MIGRAD MINIMIZATION HAS CONVERGED.
MIGRAD WILL VERIFY CONVERGENCE AND ERROR MATRIX.
                        STATUS=CONVERGED
FCN=-5679.47 FROM MIGRAD
                                               35 CALLS
                                                                36 TOTAL
                                     STRATEGY= 1
                   EDM=2.32486e-14
                                                     ERROR MATRIX ACCURATE
 EXT PARAMETER
                                              STEP
                                                           FIRST
                                ERROR
                                              SIZE
                                                        DERIVATIVE
NO. NAME
                VALUE
                                           5.63589e-09 -1.40800e+00
 1 tau
                 2.36017e-06
                             1.53148e-07
```


EX01: (E) TOY MC


Run the same experiment ~1000 times, each time generating a new dataset.


Compute τ and σ each time and check the distribution.


Analytical
LL scan
Minuit
Minuit2


au au au 2,209 0.101 2,209 0.101 2,209 0.101














EX02: SCALING

Using toy MC experiments, verify the inverse square root scaling of the error. and how the ML estimator is actually unbiased.

